

Easy Step by Step Instructions: Protecting & beautifying your blacktop driveway!

DAY 1: PREP...

PATCH

Temp at least 55° F at night. No rain in forecast



Flip pails over night prior to job



Clean: sweep or blow off – scrub & rinse any dirt or sap



If you have gas/oil spots prime them or they'll bleed through your new sealer!



Scrape out, sweep and fill cracks up to 1/2" in width.
Or try our patented Crack Stix™ or Pli Stix™. Allow to cure overnight prior to sealing.



Trowel large cracks (>1/2"), depressions & rough spots. Let it set overnight...max is 2 'lifts' – let 1st cure before 2nd.



Make sidewalks with a chisel, fill and tamp potholes. (wait 2 weeks before sealing)



Blacktop only – NO concrete
Let new blacktop cure 6 months before sealing.

Save unused Portion for touch ups – Just don't let it freeze

DAY 2: SEAL



Flip the pails over the night prior to sealing! Ensure consistency: "Batch/box" the pails using an empty pail (pouring back and forth) – Or put a mudflap on your drill if you have a lot of pails!

EDGE



Edge with a paintbrush to keep sidewalks or pavers clean...or put a sheet down.

POUR



Average coverage: 400 square ft per 4.75gal pail
*see chart on pail as coverage varies based on asphalt

APPLY



Use a Seal-Right™ Squeegee: steady down-pressure. A thick coat may track! Do project all at one time without starting/stopping to prevent color shading. For Acrylic Plus use a roller only, 3/8" nap.

ADMIRE!



No cars for 24 hours, foot traffic ready in 2 hours (or 2nd coat if needed) on a nice day.

latexite.com