

Easy Step by Step Instructions: Protecting & beautifying your blacktop driveway!

www.latexite.com

DAY 1: PREP...

PATCH...

Temp at least 55° F at night. No rain in forecast



Clean: sweep or blow off – scrub & rinse any dirt or sap



If you have gas/oil spots prime them or they'll bleed through your new sealer!



Scrape out, sweep and fill cracks up to 1/2" in width.
Or try our patented Crack Stix™ or Pli Stix™.
Allow to cure overnight prior to sealing.



Trowel large cracks (>1/2"), depressions & rough spots. Let it set overnight...max is 2 'lifts' – let 1st cure before 2nd.



Make sidewalks with a chisel, fill and tamp potholes. (wait 2 weeks before sealing)

DAY 2: MIX...

EDGE...

POUR...

PROTECT/SEAL...

ADMIRE!



Blacktop only – NO concrete
Let new blacktop cure 6 months before sealing.



It's a good idea to ensure consistency. "Batch/box" the pails using an empty pail (pouring back and forth) – Or put a mudflap on your drill if you have a lot of pails!



Edge with a paintbrush to keep sidewalks or pavers clean...or put a sheet down.



Average coverage: 400 square ft per pail
*see chart on pail



Use a Seal-Right™ Squeegee: Steady down-pressure. A thick coat may track!



No cars for 24 hours, foot traffic ready in 2 hours (or 2nd coat if needed) on a nice day