

## APPLICATION INSTRUCTIONS

**Where to Use:** Lift™ is to be used on blacktop pavement (not concrete). If new pavement, allow to cure 6 months or one full season prior to applying. Pavement can be either sealed or unsealed. Remember, for best results use the specially designed Lift™ FLEX™ Applicator. Use of roller, brush or non-Lift™ squeegees VOIDS the warranty.

**Preparation:** Pavement must be clean, dry and free of any dirt, oil, grease, pine sap before application. Power washing recommended but if not available sweep and clean off driveway and rinse away dirty residue with water.

**Repairs:** Although Lift™ will provide a uniform surface we still do recommend repairing any large cracks (1/2" or greater), depressions and potholes. Cracks can be filled with either our Pli•Stix®/Crack-Stix® product, liquid crack fillers or Trowel Patch®. Fill depressions with Trowel Patch®. Allow cracks and depression repairs to cure 24 hours prior to applying Lift™. Potholes should be filled with a stone patch – we recommend our Super Patch® (allow 2 weeks to cure before applying Lift™ on top of pothole repairs so oils can evaporate).

**Lift™ Application:** Use product when air and surface temperature is above 50°F and no rain or colder weather is in the forecast for 36 hours. Determine the appropriate number of pails necessary (see coverage chart). Make sure you have the FLEX™ Applicator as conventional driveway squeegees and roller will not work and voids warranty. Open pails and stir to an even consistency before pouring the material onto the pavement. Once completely stirred place the lids on the pails to prevent the material from skimming over. Plan on doing the entire project at once to prevent color shading and excessive squeegee marks. If driveway is extremely hot you can mist the pavement off and apply product to damp surface. If you have pavers that line the driveway or a concrete curb at end you may want to first edge the driveway with Lift™ using a wallpaper brush. Always work with gravity and pour out one pail across the width of the driveway. **Tip:** For an even finish (no ridges) slightly twist the squeegee towards your chest with top hand as you pass across driveway slightly overlapping bead. Your top hand is your right hand as you go left to right (Your top hand is your left hand as you right to left.) Apply on slight down pressure. Complete entire driveway at one time in order to prevent color shading and minimize application marks. When completed, block off driveway with empty pails. Humid or cloudy conditions will prolong curing time. Allow a minimum of 48 hours before allowing car traffic. Tight turns and power-steering marks may leave abrasion marks due to the thickness of product. Marks will wash and fade away with time. Deeper marks from plows may require recoating.

**Coverage:** Coverage rates are determined using Lift™ FLEX™ Applicator (Use of roller, brush or non-Lift™ squeegees VOIDS the warranty). Approximate coverage: 200 square feet per 4.75 gallon pail. Note: Less coverage will be obtained when applying on rough/porous/unsealed surface: approximately 125 - 150 square feet.

**Clean-Up:** While wet, clean tools with soap and water. If dry, use any citrus based cleaner and scrub.

**Precautions:** Do not mix this product with any other driveway products. Do not dilute. Protective clothing and eyewear should be worn during application. When transporting product make sure lid is securely attached and pail is secured and upright. Do not re-use empty containers. Dispose of in an environmentally acceptable manner. This container is recyclable if cleaned immediately. Do not pour excess product in drains or watercourses. **KEEP FROM FREEZING.** Seal container when not in use.